

# PA-U0405-NULQ

# 4-Channel CCTV "Brick" Power Supply Manual







<u>C E 🕾</u>

#### **ENFORCER 4-Channel CCTV "Brick" Power Supply**

#### Introduction:

The PA-U0405-NULQ is a 4-channel 5-Amp power supply. While normally used in CCTV installations, it is suitable for a wide variety of both CCTV and access control applications. It features adjustable output voltage and built-in 6.8-Amp overcurrent protection.

#### Features:

- 4-Channel 5-Amp power distribution •
- Universal input voltage: 100~240 VAC •
- Adjustable output voltage: 12~13.8 VDC •
- Built-in 6.8-Amp overcurrent protection
- High voltage and overcurrent protection •
- LED Power indicator
- Mounting bracket included for easy installation

#### Parts List:


- Power supply x1 Power cable
  - x1

- Mounting bracket x1
- Mounting screws x2

#### Specifications:

Outputs	4	
Total supply current	5A	
Max. output power	60W	
Overcurrent protection	6.8A	
Output voltage	12~13.8 VDC	
Input fuse	3.15A@250VAC	
Input voltage	100~240 VAC	
Dimensions	5 <sup>7</sup> /8"x2 <sup>3</sup> / <sub>16</sub> "x1 <sup>5</sup> / <sub>16</sub> " (150x55x33 mm)	
Weight	13.4-oz (380g)	
Operating temperature	14°~113° F (-10°~45° C)	

#### Overview:




#### Installation:


- Find a suitable location to install the power supply. The power supply should be installed out of sight, and in a place protected from weather and high humidity. The power supply must have adequate ventilation. Insufficient ventilation may cause overheating and damage could result.
- Attach the power supply to a wall or desk using the included mounting bracket. If
  possible, mount the power supply sideways or with the terminals facing down so they do
  not collect dust.
- 3. Connect the main power cable to the power supply.

### Wiring and Adjusting Voltage:

- Connect cameras and other devices to the power outputs, while observing correct polarity as shown in Figure 1. To minimize voltage drop, use 18-gauge or larger wire.
   WARNING: Always test output voltage before connecting devices to the power supply.
- 2. If voltage drop is large, adjust the output voltage potentiometer as shown in Figure 2.



### Sample Installation:



#### Troubleshooting:

Camera will not turn on	<ul> <li>Make sure that all wires are connected securely and that the polarity is correct</li> </ul>
No output power from power supply	<ul> <li>Check to see that the main power cable is securely connected to the AC wall socket</li> <li>Make sure that the AC wall socket is powered</li> <li>Check LED indicators on power supply to ensure that input power is being received</li> <li>Check the total supply current for all connected device does not exceed 5A</li> </ul>

#### Also Available from SECO-LARM:



LIMITED WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.

**NOTICE:** The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors. Trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners.

Copyright © 2015 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

## SECO-LARM<sup>®</sup> U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606	Website: www.seco-larm.com	A. PICSN7
Phone: (949) 261-2999   (800) 662-0800	Email: sales@seco-larm.com	MiPA-U0405-NULQ_150806.docx