Two Systems in One Alarm 1. Upgrade to Factory Keyless Entry System Connect to most vehicles' factory keyless entry systems to provide a complete security system which is operated Lock/Arm by the vehicle's remote controls. Unlock/ Disarm 2. Keyless Entry/Alarm System Use the SECO-LARM SK-919T4J transmitters with Unlock/ Lock/Arm the SLI-820R for a complete alarm system. Disarm Press 🛪 then 🕞 for silent arm/lock. Press \star then \mathbf{f} for silent disarm/unlock. Panic Press and hold \star for channel 2. FEATURES INCLUDE: Model: SK-919T4J Easily turns most factory keyless entry systems into complete security systems. **Optional ENFORCER** • Two systems in one: remote Connect to factory keyless entry systems for full security features. Add ENFORCER remotes for a complete stand-alone security system. Additional features when ENFORCER remote is used: 2nd channel output, dedicated panic button, sensor bypass, and chirp delete. Automatically learns the polarity of vehicle's door locks. Disarm defeat input prevents thieves from using car's unlock switch to disarm alarm.

ENFORCER[®] 5LI 820R

- Includes dual-stage electronic shock sensor.
- Built-in parking light relay flashes to indicate alarm armed, disarmed, triggered, pre-intrusion, zone bypass, valet, and tamper.
- Patented Stay-Safe Disarm[™].
- Multi-function LED indicates alarm arming, armed, disarmed, triggered zone and valet.
- Multi-function pushbutton for valet, emergency disarm.
- Starter disable output.
- Siren (+) and horn (-) outputs. Chirps to indicate arming, armed, disarmed, valet, zone bypass, pre-intrusion and zone triggered.
- 5 instant-triggering zones.
- 14 Programmable functions.

16842 Millikan Avenue, Irvine, CA 92606

Tel: 1-800-662-0800 (Domestic U.S. & Canada) Tel: 1-949-261-2999 (California & international) Fax: 1-949-261-7326 Email: info@seco-larm.com Website: www.seco-larm.com

CES2004_HandoutsC.pmd

