TROUBLE SHOOTING

IR LEDs do not turn on	Check that the AC adapter is plugged into a power outlet.
	 Check that the AC adapter is plugged into the dummy camera.



IMPORTANT:

Users and installers of this product are responsible for ensuring this product complies with all national, state, and local laws. **SECO-LARM** is not responsible for the use of this product in violation of any current laws or statutes.

WARRANTY:

This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM.

This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair, or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship.

The sole obligation of SECO-LARM, and the purchaser's exclusive remedy, shall be limited to replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damages of any kind to the purchaser or anyone else.

NOTICE:

The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice.

SECO-LARM is also not responsible for misprints or typographical errors.

Copyright © 2008 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

SECO-LARM® U.S.A., Inc., 16842 Millikan Avenue, Irvine, CA 92606 Tel: 800-662-0800 / 949-261-2999 Fax: 949-261-7326 Website: www.seco-larm.com E-mail: sales@seco-larm.com Page 4

CBA® VD-10PL Dummy Camera with Real Working IR LEDs Installation Manual



Included: 1 x Dummy Camera 1 x Sun shield 1 x Mounting bracket 3 x Mounting screws 3 x Plastic screw anchors 1 x Manual

Note: This dummy camera is to be used as a deterrent only. **SECO-LARM® U.S.A., Inc.**

VD-10PL – Dummy IR Bullet Camera with real working IR LEDs



- Includes dummy camera module with real working IR LEDs.
- Metal mounting bracket included.
- Constructed of strong ABS plastic.

How It Works

The SECO-LARM VD-10PL dummy camera is a great low-cost way to deter crime at home, in an office, a parking lot, and around playgrounds. The dummy camera creates the perception of electronic surveillance without the high cost, high maintenance, and upkeep of real CCTV cameras, monitors and DVR's.

Unlike most dummy cameras, the IR LEDs of the VD-10PL turn on automatically when it is dark or when the lights are turned off, and turn off when it is light or the lights are turned on.

Criminals are more likely to move on to an easier target if they know their activities may be recorded.

Mix dummy cameras with real cameras to make the dummy cameras more believable.

Installation:

1. Chose a suitable location. Usually, the higher up a dummy camera is, the more authentic it will appear.

2. Plug the optional AC power adapter into a power outlet, and run the adapter's wire to where the dummy camera will be mounted.

NOTE 1 - For a more professional and realistic appearancel, run the adapter's wire through the wall so the wire is hidden.

NOTE 2 - The battery compartment is not used. Do not install battery in the battery compartment.


- 3. Screw the mounting bracket into the bottom of the dummy camera.
- 4. Connect the adapter's wire to the power connector of the dummy camera.
- 5. Hide the dummy camera's BNC connector so no one can see that it is not connected to a monitor.

NOTE - BNC connector is not used. For looks only.

- 6. Mount the bracket's base to the wall, using the three included mounting screws. If the wall is made of dry wall, brick, or similar material, it may be necessary to use the included plastic screw anchors.
- 7. Do a final test of the dummy camera with the lights turned on and turned off.

Check out SECO-LARM's full line of dummy cameras.

	Model # and Description
	 VD-30BS - Dummy IR Bullet Camera (non-working IR) Incorporates a realistic camera with video/power cables (one cable) to give it an authentic look. Metal mounting bracket included. Single flashing battery-powered LED. Requires 2 AA batteries (not included). Constructed of strong ABS plastic.
0	 VD-20NN Dummy Dome Camera Incorporates a realistic camera module to give it an authentic look. Constructed of strong ABS plastic.
	 VD-10BN Dummy Security Camera Incorporates a realistic camera with a battery-powered LED to give it an authentic look. Includes simulated Video and power cable. Includes simulated Video and power Constructed of weatherproof aluminum metal housing.
	 VD-40BN – Dummy PTZ Speed Dome Camera Incorporates a realistic camera with a battery-powered LED to give it an authentic look. Indoor / outdoor use. Weatherproof ABS plastic housing. Metal wall mount bracket included. Requires 2 AA batteries (not included) Threaded conduit fittings allow for extended mounting.
	 VD-10BNA Dummy Box Camera Incorporates a realistic camera with video/power cables (one cable) to give it an authentic look. Battery-powered LED. Requires 2 AAA batteries (not included). Constructed of strong ABS plastic.
	 VB-HC1 – Ceiling mount bracket for PTZ Speed Dome For model VD-40BN PTZ speed dome. 9" pipe with hole for easy access to wires. Threaded conduit fittings.



Page 2