



SECO-LARM[®]
www.seco-larm.com

Dummy Keypad

KD-100Q

The dummy keypad has flashing LEDs, emits a beep when keys are pressed, and features a professional-looking stainless steel housing—just like a real working keypad.

INSTALLATION

1. Remove the faceplate from the base by loosening then removing the two screws on the faceplate.
2. The base has battery compartments on both sides. The keypad can operate for 1 (one) year on 2 "AAA" batteries, and 2 (two) years on 4 batteries (AAA, not included).
3. Locate the mounting screw holes on the top and bottom edges of the keypad base.
4. Using the included screws, mount the keypad on an indoor or outdoor wall next to an entry door where it is clearly visible.
5. Replace the metal faceplate but make sure not to over-tighten the screws.
6. When the keypad beeps or LED flashes become weak, new batteries are needed.

Copyright © 2008 **SECO-LARM** U.S.A., Inc.
CBA[®] is a registered trademark.



Please recycle for
a cleaner environment.
PHLKT

SECO-LARM makes no warranties expressed or implied that dummy cameras will prevent any criminal or inappropriate activity. SECO-LARM disclaims any and all liability for any damages to property or persons as a consequence of the purchase or installation of dummy cameras. Neither SECO-LARM nor any of its officers or employees or resellers shall be subject to any liability arising out of or in connection with this sale. The purchaser assumes all risk and all liability arising out of the installation of dummy cameras.



D:\jans\BOXING\KD100Q_CBA_0808