

**LHR DOOR
INSIDE FACE**

ENFORCER®

**GRADE 1
RIM-TYPE EXIT DEVICE
MOUNTING TEMPLATE**

3 Mounting Holes :
Metal Door – Drill/Tap for 1/4" -20 machine screws
Wood Door – 1/8" Pilot Drill

Mounting Holes : A,B,C,D 4 places
Metal Door :
For Mounting Screws – Drill/Tap for 1/4-20 machine screws
For Sex Bolts – Drill 5/16" (8 mm) inside hole
Drill 13/32" (10 mm) outside hole
For Trim – Drill 5/16" (8 mm) inside hole
Drill 1/2" (13 mm) outside hole
Wood Door :
For Sex Bolts only – Drill 13/32" (10 mm) through holes
For Trim – Drill 1/2" (13 mm) through holes


Trim Actuating Shaft Hole :
Drill 1/2" (13 mm) through hole for BE & CE trims
For NL trim hole requirement, see its template
(Not required for dummy trim)

2 Mounting Holes :
Metal Door – Drill/Tap for 1/4-20 machine screws
Wood Door – 1/8" (3 mm) Pilot Drill for wood screws

PLACE THIS SIDE ON FRAME STOP OR MULLION

PLACE THIS SIDE ON DOOR

FOLD HERE



Install this screw after adjusting the strike so that it is aligned with the latchbolt.

Mark the mounting holes through the end cap bracket after the device is in place.

**RHR DOOR
INSIDE FACE**

NOTE:

1. For a grade 1 entry-type lever trim (not included), use mounting holes A, B, C, and D. For a grade 2 entry-type lever trim (not included), use mounting holes X and Y. For any other trim, please refer to that trim's template or manual.
2. If device doesn't use a trim, use mounting holes A, B, C, and D to install the chassis.
3. Make sure the final centerline of the device and strike is 40" (1m) from the floor.
4. A 1/4" (6mm) gap between the bottom of the door and the floor is required.